


**HOSE ASSEMBLIES - FLARED TO FLARED**

CONFIGURATION END A    END B	SIZE	STAINLESS STEEL R270 ASSEMBLY BASE NO.	ALUMINIUM R270 ASSEMBLY BASE N°
Straight to Straight	-4 thru -16	510000	512020
Straight to 45°	-4 thru -16	510001	512021
Straight to 90°	-4 thru -32	510002	512022
45° to 45°	-4 thru -16	510101	512121
45° to 90°	-4 thru -16	510102	512122
90° to 90°	-4 thru -16	510202	512222

ASSEMBLIES



**HOSE ASSEMBLIES - FLARELESS TO FLARELESS**

CONFIGURATION END A    END B	SIZE	STAINLESS STEEL R270 ASSEMBLY BASE NO.	ALUMINIUM R270 ASSEMBLY BASE N°
Straight to Straight	-4 thru -16	510606	512626
Straight to 45°	-4 thru -16	510614	512634
Straight to 90°	-4 thru -16	510615	512635
45° to 45°	-4 thru -16	511414	513434
45° to 90°	-4 thru -16	511415	513435
90° to 90°	-4 thru -16	511515	513535



The above are basic configuration style numbers. Refer to page 8 for complete part number.